

# Network Analyzer User Manual



**ADDRESS: Ikitelli OSB Mah. Cevre 14.  
Blok Sok. Telas Blok Dis Kapi No: 1  
Kat: 1-2 Basaksehir/Istanbul**

**Phone: +90 212 438 80 24  
Fax: +90 212 438 80 25**

**info@gruparge.com**

# CONTENTS

<b>CONTENTS</b>	<b>2</b>
<b>PROPER USE AND SAFETY CONDITIONS</b>	<b>5</b>
<b>1. INTRODUCTION</b>	<b>6</b>
1.1. General Features	6
1.2. Technical Features	6
1.3. Technical Drawing of Network Analyzer	8
1.4. Connection Diagram	9
1.5. Measurable Line Parameters	10
1.6. Buttons and Functions	10
<b>2. INSTALLATION</b>	<b>11</b>
2.1. Device Installation	11
2.2. Installation Menu	11
<b>3. MAIN SCREEN AND SUB SCREENS 3.1.</b>	<b>12</b>
3.1. Main Screen Overview	12
3.2. Voltage-Current Screen	14
3.2.1. Voltage (Phase to Phase) - Frequency	14
3.2.2. Voltage-Current Angle and Unbalance	14
3.2.3. Voltage-Current Min/Max (Consumption)	14
3.2.4. Voltage-Current Min/Max (Production)	15
3.2.5. Voltage-Current Demand (Consumption)	15
3.2.6. Voltage-Current Demand (Production)	16
3.3. Active - Reactive Powers Main Screen	16
3.3.1. Power Triangle	16
3.3.2. Apparent Active - Reactive Power	17
3.3.3. Active - Reactive Power Min/Max (Consumption)	18
3.3.4. Active - Reactive Power Min/Max (Production)	18
3.3.5. Active - Reactive Demand (Consumption)	19
3.3.6. Active - Reactive Demand (Production)	20
3.4. Voltage-Current Harmonics (%)	20
3.5. Cosine and Phase Diagram Main Screen	20
3.5.1. Power Factor	21
3.6. Energy Indices	22
3.6.1. Energy Consumption	22

3.6.2. Energy Consumption	22
3.6.3. All Energies	23
3.6.4. Energy Ratio (Consumption)	23
3.6.5. Energy Ratios (Production)	23
<b>4. ANALYZER MAIN MENU</b>	<b>24</b>
4.1. Fast Menu	24
4.1.1. Current Transformer Ratio	24
4.1.2. Modbus Address	25
4.2 Analayzer	25
4.2.1. Harmonics	25
4.2.2. Delete Energies	26
4.2.3. Delete Peak Values	26
4.2.4. Demands	26
4.3. Digital Output	27
4.3.1. Select Size	27
4.3.2. Select Phase	31
4.3.3. Reverse Output	31
4.3.4. Upper Limit Value	31
4.3.5. Lower Limit Value	31
4.3.6. Start-up Time	31
4.3.7. Deactivation Time	31
4.4. Events	31
4.4.1. Make a list	31
4.4.2. Alarm Icon	32
4.4.3. Delete	32
4.5. User Manual	32
4.6. Settings	32
4.6.1. Measurement & Transformers	32
4.6.2. Modbus Settings	33
4.6.3. Screen Settings	33
4.6.4. Date & Time	33

4.6.5. Expert Settings	34
4.6.6. Device Information	34

## PROPER USE AND SAFETY REQUIREMENTS



Cut all the power when connecting and disconnecting the device to a panel.



Do not clean the device with a solvent or similar material. Only use a dry cloth.



Please do not intervene to the device when a technical problem is encountered and get in contact with a technical service within the shortest time.



If the warnings are not taken into account, our company or the authorized dealer shall not be held responsible for the negative consequences.



Do not dispose in the trash, the device must be delivered to the collection centers (electronic device recycling centers). It should be recycled or disposed of without harming human health and environment.



The installation, assembly, activation and operation of the device should be done and used by only expert professionals and in accordance with safety regulations and instructions.



The device operates with current transformers. Do not strictly leave current transformer tips unattached. Dangerous high voltage can occur.

# 1. INTRODUCTION

## 1.1. General Features

Network analyzer: 3 phase currents and neutral current, phase-neutral and phase-phase voltages, frequency, active and reactive powers, angle difference between current and voltage, power factor, current and voltage harmonics between 1-31 and current and voltage Total Harmonic Distortion values of each phase. In addition, it reads and records active and reactive energies.

Demand and peak values for these measured quantities can also be monitored on the analyzer.

Many necessary adjustments related to the device (Current Transformer, Voltage Transformer, etc.) can be made through the menu.


In the communicated versions, all read parameters can be monitored remotely via the standard MODBUS protocol and various adjustments can be made.

## 1.2. Technical Features


- RS-485 supports standard MODBUS RTU protocol communication channel.
- For Modbus RTU, the device supports 4800, 9600, 19200, 38400, 57600 and 115200 bps speeds.
- The operating ambient temperature of the device is between -10 °C and +55 °C.
- The power consumption of the measurement inputs is less than 1 VA.
- Line voltage can be adjusted in the range of (L-L) 90 V-46000 V
- Line voltage can be adjusted in the range of (L-N) 50 V-26560 V
- Measuring voltage can be adjusted in the range of (L-L) 22 V-1000 V (45-65 Hz)
- Measuring voltage can be adjusted in the range of (L-N) 13 V-575 V (45-65 Hz)
- Current transformer ratio can be adjusted between 5/5 and 10000/5.
- Optionally, it can be compatible with CT30 type current transformer.
- Operating frequency is 45-65 Hz.
- Minimum measurement value is 1 mA / 2 V.
- Measurement accuracy is 1mA / 0.1 V.

- Periodically saves the peak values of energy, demand and all parameters in permanent memory. Even if the power is turned off, the device continues to record the corresponding values from where it left off when it is turned on again.
- Demand measurement time can be set between 1-60 minutes.Dec.
- All device parameters can be monitored remotely via RS-485 communication channel.
- The peak values of energy, demand and all line parameters should be reset from the device menu.
- Our Network Analyzer product has 1 digital output with optocoupler.
- Our Network Analyzer product has a 3.5-inch 320x480 resolution color TFT display.
- Network Analyzer device dimensions (Aspect-Length-Depth) are 97.5 x 97.5 x 50.5 mm.
- Our Network Analyzer product operates under 85-265 V AC voltage.
- Our Network Analyzer product has IP20 protection class.
- Measurement of Current and Voltage harmonics from 1 to 31 Decimals
- Measurement of Current and Voltage Total Harmonic Distortions


### 1.3. Network Analyzer Technical Drawing



FRONT VIEW




SIDE VIEW



TOP VIEW



## 1.4. Connection Diagram



## 1.5. Measurable Line Parameters

- Phase-Neutral Voltages (V11, V12, V13)
- Phase-to-phase voltages (V12, V23, V13)
- Phase Currents (I1, I2, I3,  $\Sigma I$ )
- Neutral Current (  $I_n$  )
- Frequency
- Active Power (P1, P2, P3,  $\Sigma P$ )
- Reactive Power
- Capacitive Reactive Power (  $\Sigma Q(\text{cap})$ , Q1(cap), Q2(cap), Q3(cap) )
- Inductive Reactive Power
- Visible Power (  $\Sigma S$ , S1, S2, S3 )
- Power Factors (PF1, PF2, PF3)
- Active Energy (Import / Export,  $\Sigma Wh$ )
- Reactive Energy (Import / Export,  $\Sigma VARh$ )
- Min/Max Values (Import / Export)
- Demand Values (Import / Export)
- Voltage and Current Harmonics of Each Phase (between 1- 31)
- Total Harmonic Values of Current and Voltage (THDU and THDI)
- $\cos\phi$  and  $\tan\phi$  values of each phase
- % Current and % Voltage Imbalances
- Current and Voltage Phase Angles
- Power Triangle
- Phasor Diagram

## 1.6. Buttons and Functions

There are 5 buttons on the device and their functions change according to the current screen. When navigating between screens, the yellow buttons shown in the picture below allow you to switch between the main screens and the white buttons on the left allow you to switch between the sub-screens of the selected main screen. The nomenclature of the buttons changes according to the main screen and sub-screens to be navigated when the relevant button is pressed.



The green button on the far right has 2 functions. Pressing this button opens the menu of the device. When this button is pressed and held, the main measurement screen of the device opens. In this way, the user can access the main screen in a very short time by long pressing this button.

Each time the buttons are pressed, arrow keys will appear on the screen to help the user with the direction of progress.



When the menu button is entered, the buttons have the functions shown in the picture below. Exit button is used to exit the menu directly. The back button is used to exit back from the current menu screen.



## 2. INSTALLATION

### 2.1. Device Installation


Make the current and voltage input connections of your device according to the diagrams on **Page 8** and **Page 9**. When connecting your device, make sure that the current and voltage inputs are correctly matched. After checking the connections and making sure that they are correct, give energy to your device.

NOTE : **Menu** > **Settings** > **Expert** in the "Device Reset" section, "Device Reset" is confirmed and the device returns to the initial setup settings.

### 2.2. Installation Menu



After your device is energised, you will first see the serial number screen on the left. This screen gives information about the serial number of your device. **Confirm** after confirming with the button, the current transformer ratio menu appears on the screen as follows.



In this screen, the current transformer ratio is set with the direction buttons and confirmed by pressing the **Confirm** button.

Then, the language selection screen appears as below. After selecting the required language option

✓ **Confirm** by pressing the confirm button.



### 3. MAIN SCREEN AND SUB SCREENS

The device has a total of 9 main screen titles. The image below shows the default main screen after installation.

NOTE : If you want to return to the main screen while navigating between other main screens and sub-screens, press and hold the button under "Menu".









#### 3.1. Main Screen General Overview

Voltage-Current (RMS)				30.0 °C	1
V1	220,7 v	I1	0,968 A		2
V2	220,3 v	I2	1,141 A		
V3	220,9 v	I3	0,985 A		
Vort	220,2 v	IN	0,001 A		
S.No:00189101		CT: 5/5		26.05.2021 11:22	3
VLL-Frks	VA-Dmd (Ü)	HL_Grfk	P-Q	MENU	

**(1) Information Bar:** Is the part where various symbols such as relay on/off, alarm, communication, RTC battery status are located.

**(2) Title Bar:** This section shows the screen titles navigated on the device. The temperature value is also shown in this section.

**(3) Bottom Status Bar:** Date and time information, current transformer ratio and device serial number are available in this section. At the same time, various warnings are given to the user via this bar. If the bottom warning bar is colored blue, it means that the device has not been quality tested and a quality control test should be performed by going to the quality control section from the expert settings in the menu. If the color of the bar is burgundy, the Quality Control test has been performed and the device is working properly. If the company name is written via modbus, the company name is shown in this status bar at intervals.

		Digital output position is indicated by this symbol which flashes yellow during recording. If the digital output on-off time is available, this symbol is colored green-yellow during counting and the counted time information is notified to the user.
		If an alarm occurs, the alarm symbol is colored red.
		The symbol indicating the RTC battery status will be colored red when the RTC battery is low.
		This symbol indicates that the device has modbus communication feature. When the device exchanges data with modbus, the arrows in the sending and receiving direction are painted in different colors.

### 3.2. Voltage-Current Display

The next screen is the main screen of the device. The device starts with this screen when it is first turned on. Phase-Neutral voltages and average voltage are shown on the left side of the screen, while current values of each phase and neutral current are shown on the right side of the screen. This main screen has many sub screens. You can switch to the sub-screens with the white buttons on the left side.

Voltage-Current (RMS)				30.0 °C
V1	220,7 v	I1	0,968 A	
V2	220,3 v	I2	1,141 A	
V3	220,9 v	I3	0,985 A	
Vort	220,2 v	IN	0,001 A	
S.No:00189101		CT: 5/5	26.05.2021	11:22
VLL-Frkns	VA-Dmd (Ü)	HI_Grfk	P-Q	MENU

By pressing the "VLL-Frkns" button while on this screen, you can switch to the Voltage (Phase-Phase) - Frequency sub-screen.

#### 3.2.1. Voltage (Phase-Phase) - Frequency

The screen on the side shows the phase-phase values of the voltage and the frequency values of each phase. The average voltage of the phases and the average frequency of the phases can also be seen on this screen.

Voltage (Phase-Phase) - Frequency				30.0 °C
U12	370,0 v	F1	50,0 Hz	
U23	369,9 v	F2	50,0 Hz	
U31	372,8 v	F3	50,0 Hz	
Vort	380,0 v	Fort.	50,0 Hz	
S.No:00189101		CT: 5/5	26.05.2021	11:22
VA-Asmtr	V-A	HI_Grfk	P-Q	MENU

While on this screen, VA-Asmtr By pressing the bottom button, you can switch to the Voltage-Current Angle and Imbalance screen.

#### 3.2.2. Voltage-Current Angle and Unbalance

The left side of the screen shows the fund value of the voltage for each phase, the angle differences between the phase voltages and the % voltage asymmetry value. The right part of the screen shows the fund value of the current for each phase, the angle differences between the phase currents and the % current asymmetry value.

Voltage-Current Angle and Unbalance				30.0 °C
Vfund1	213,9 v	Ifund1	0,945 A	
U12 $\phi$	239°	I12 $\phi$	122°	
Vfund2	214,8 v	Ifund2	1,089 A	
U23 $\phi$	119°	I23 $\phi$	277°	
Vfund3	213,8 v	Ifund3	0,943 A	
U13 $\phi$	119°	I13 $\phi$	204°	
V% Asimetri	0,2	I% Asimetri	10,3	
S.No:00189101		CT: 5/5	26.05.2021	11:22
VA-Tepe(T)	VLL-Frkns	HI_Grfk	P-Q	MENU



When the **VA-Tepe(T)** button is pressed while on this screen, it is possible to switch to the **Voltage Current Min Max (Consumption)** sub-screen.

### 3.2.3. Voltage-Current Min/Max (Consumption)

The screen on the left shows the minimum and maximum consumption values of the current and voltage values of each phase separately.

Voltage-Current Min/Max (Consumption)						30.0 °C
V1	Max	216,4 v	I1	Max	0,975 A	
	Min	213,5 v		Min	0,000 A	
V2	Max	216,6 v	I2	Max	0,007 A	
	Min	213,8 v		Min	0,000 A	
V3	Max	215,8 v	I3	Max	0,007 A	
	Min	213,0 v		Min	0,000 A	
S.No:00189101		CT: 5/5		26.05.2021 11:22		
VA-Tepe(Ü)		VA-Asmtr		HI Grfk	P-Q	
				MENU		

By pressing the **VA-Tepe(Ü)** button on this screen, you can switch to the Voltage Current Max (Production) sub-screen.

### 3.2.4. Voltage-Current Min/Max (Production)

The screen on the left shows the minimum and maximum production values of the current and voltage values of each phase separately.

<div><div></div><div>Voltage-Current Min/Max (Production)</div></div>						30.0 °C		
V1	Max	215,3 v	I1	Max	1,007 A			
	Min	213,5 v		Min	0,001 A			
V2	Max	216,3 v	I2	Max	1,149 A			
	Min	214,7 v		Min	0,001 A			
V3	Max	215,3 v	I3	Max	1,007 A			
	Min	213,5 v		Min	0,001 A			
S.No:00189101						CT: 5/5	26.05.2021	11:22
VA-Dmd (T)		VA-Tepe (T)		HI Grfk	P-Q	MENU		

By pressing the **VA-Dmd(T)** button on this screen, you can switch to the **Voltage Current Demand (Derivation)** sub-screen.

### 3.2.5. Voltage-Current Demand (Consumption)

On the next screen, the minimum and maximum consumption values of current and voltage demands are shown separately for each phase.

<div></div> <div>1L</div>					
Voltage-Current Demand (Consumption)					30.0 °C
DV1	Max	215,7 v	DI1	Max	0,001 A
	Min	214,6 v		Min	0,001 A
DV2	Max	215,9 v	DI2	Max	0,001 A
	Min	214,6 v		Min	0,001 A
DV3	Max	215,1 v	DI3	Max	0,001 A
	Min	213,9 v		Min	0,001 A
S.No:00189101		CT: 5/5		26.05.2021	11:22
VA-Dmd (Ü)		VA-Tepe (Ü)		HI Grfk	P=0 <div> MENU</div>

By pressing the **VA-Dmd(Ü)** button on this screen, you can switch to the Voltage-Current Demand (Production) sub-screen.

### 3.2.6. Voltage-Current Demand (Production)

The screen on the left shows the minimum and maximum values of current and voltage demands for each phase for production values.

Voltage-Current Demand (Production)					30.0 °C
DV1	Max	215,7 v	DI1	Max	0,001 A
	Min	214,6 v		Min	0,001 A
DV2	Max	215,9 v	DI2	Max	0,001 A
	Min	214,6 v		Min	0,001 A
DV3	Max	215,1 v	DI3	Max	0,001 A
	Min	213,9 v		Min	0,001 A
S.No:00189101		CT: 5/5		26.05.2021 11:22	
V-A	VA-Dmd (T)	HI_Grfk	P-Q	MENU	

### 3.3. Active - Reactive Powers Main Screen

The left side of the screen shows active powers for each phase and total imported and exported active powers separately. On the right side of the screen, reactive powers, total import and export reactive powers are shown separately for each phase. The inductive - capacitive status of the powers is expressed by the coil and capacitor drawn next to the values. This main screen has many sub screens. You can switch to the sub screens with the white buttons on the left side.

Active - Reactive Powers Main Screen 30.0 °C					
P1	15 W	Q1	76 VAr		
P2	16 W	Q2	73 VAr		
P3	16 W	Q3	76 VAr		
$\Sigma P_i$	47 W	$\Sigma Q_i$	225 VAr		
$\Sigma P_e$	0 W	$\Sigma Q_e$	0 VAr		
S.No:00189101		CT: 5/5		26.05.2021 11:22	
Güç Grfk.	PQ-Dmd (Ü)	V-A	Cosφ	MENU	

While on this screen, you can switch to the **Power Triangle** sub-screen by pressing the **Power Grfk.** button.




### 3.3.1. Power Triangle


The power triangle graph is shown in the center of the next screen. In the power triangle, red thick lines are active, blue thick lines are reactive and green thick lines are visible power.

The graph is divided into two parts by the export and import axes and consists of four regions. The left side of the graph shows the export and the right side the import values. The export part with the red line is the part where the export power triangle will be drawn for inductive and capacitive values. The import section with the blue line is where the import power triangle will be drawn for inductive and capacitive values.

In the four regions in the graph, there are "L1", "L2", "L3" expressions indicating the state of the phases in each region. For example, while L1-L2 phases are operating in the inductive import region, L3 phase is operating in the capacitive export region.



In places outside the graph, total active, reactive and apparent powers are shown for export values on the left side of the screen. On the right side of the screen, total active, reactive and apparent powers are shown for import values.



When the **P-Q-S** button is pressed on this screen, it will shoe the Apparent Active - Reactive Power sub screen.

### 3.3.2. Apparent Active - Reactive Power

Apparent Active -The left side of the screen shows the apparent powers for each phase. The right side of the screen shows the active and reactive powers for each phase.

Apparent Active - Reactive Power					30.0 °C
S1	112 VA	P1	93 W	Q1	62 VAr
S2	106 VA	P2	-6 W	Q2	100 VAr
S3	212 VA	P3	-102 W	Q3	-175 VAr
S.No:00189101		CT: 5/5		26.05.2021 11:22	
PQ-Tepe (T)	Güç Grfk.	V-A	Cosφ	MENU	

While on this screen, pressing the **PQ-Tepe (T)** button switches to the **Active Reactive Min/Max (Consumption)** sub-screen.

### 3.3.3. Active - Reactive Power Min/Max (Consumption)

At the left side of the screen, minimum and maximum active powers of each phase for consumption values are shown separately. The right side of the screen shows the reactive power of each phase separately for consumption values. In the reactive power display, capacitance and inductive symbols are drawn in front of the value according to the capacitive or inductive status of the minimum and maximum values of the phase.

Active - Reactive Power Min/Max (Consumption)					30.0 °C
P1	Max	306 W	Q1	Max	63 VAr
	Min	0 W		Min	-58 VAr
P2	Max	0 W	Q2	Max	0 VAr
	Min	0 W		Min	0 VAr
P3	Max	0 W	Q3	Max	0 VAr
	Min	0 W		Min	0 VAr
S.No:00189101		CT: 5/5		26.05.2021 11:22	
PQ-Tepe (Ü)	P-Q-S	V-A	Cosφ	MENU	

By pressing the **PQ-Tepe(Ü)** button while on this screen, you can switch to the Active Reactive Min/Max (Production) sub-screen.

### 3.3.4. Active - Reactive Demand (Consumption)

The left side of the screen shows the active maximum and minimum demands of each phase separately for consumption values. The right side of the screen shows the reactive maximum and minimum demands of each phase separately for consumption values.

<div> </div>					1L
Active - Reactive Demand (Consumption)					30.0 °C
DP1	Max	12 W	DQ1	Max	19 VAr
	Min	12 W		Min	19 VAr
DP2	Max	11 W	DQ2	Max	2 VAr
	Min	11 W		Min	2 VAr
DP3	Max	12 W	DQ3	Max	8 VAr
	Min	12 W		Min	8 VAr
S.No:00189101		CT: 5/5	26.05.2021		11:22
PQ-DMD (Ü)	PQ-Tepe (Ü)	V-A	Cosφ	MENU	

By pressing the **PQ-Dmd(Ü)** button on this screen, you can switch to the Active - Reactive Demand (Production) sub-screen.

### 3.3.5. Active - Reactive Demand (Production)

The left side of the screen shows the active maximum and minimum demands of each phase separately for production values. On the right side of the screen, reactive maximum and minimum demands of each phase separately for production values are shown.

<div> </div>					1L
Active - Reactive Demand (Production)					30.0 °C
DP1	Max	0 W	DQ1	Max	0 VAr
	Min	0 W		Min	0 VAr
DP2	Max	0 W	DQ2	Max	0 VAr
	Min	0 W		Min	0 VAr
DP3	Max	0 W	DQ3	Max	0 VAr
	Min	0 W		Min	0 VAr
S.No:00189101		CT: 5/5	26.05.2021		11:22
P-Q	PQ-Dmd (T)	V-A	Cosφ	MENU	

By pressing the **PQ-Dmd(Ü)** button on this screen, you can switch to the Active - Reactive Demand (Production) sub-screen.

### 3.3.6. Active - Reactive Demand (Production)

The left side of the screen shows the active maximum and minimum demands of each phase separately for production values. On the right side of the screen, reactive maximum and minimum demands of each phase separately for production values are shown.

Active - Reactive Demand (Production)						30.0 °C
DP1	Max	0 W	DQ1	Max	0 VAr	
	Min	0 W		Min	0 VAr	
DP2	Max	0 W	DQ2	Max	0 VAr	
	Min	0 W		Min	0 VAr	
DP3	Max	0 W	DQ3	Max	0 VAr	
	Min	0 W		Min	0 VAr	
S.No:00189101		CT: 5/5	26.05.2021		11:22	
P-Q	PQ-Dmd (T)	V-A	Cosφ	MENU		

### 3.4.Voltage-Current Harmonics (%)

The screens on the side and below list the harmonic values for current and voltage in %. The device is capable of measuring up to the 31rd harmonic. The user can set the harmonics and the number of harmonics to be listed in the menu. If the user selects all harmonics from the menu, all harmonics are listed on this screen.

Voltage-Current Harmonics (%)						30.0 °C
Hrmnk	V1	V2	V3	I1	I2	I3
%THD	3,0	2,8	2,8	19,1	30,9	29,2
%H3	0,5	0,8	0,8	1,1	2,3	2,2
%H5	2,2	2,2	2,0	17,5	13,0	13,8
%H7	0,9	1,0	0,8	7,7	10,7	7,8
%H9	0,9	1,0	0,8	3,5	16,1	9,9
%H11	0,2	0,0	0,2	0,7	2,7	3,5
%H13	0,3	0,1	0,3	0,7	6,7	5,9
S.No:00189101		CT: 5/5	26.05.2021		11:22	
%HV-HI ↓	%HV-HI ↑	Energy	HV_Rms	MENU		

Voltage-Current Harmonics (%)						30.0 °C
Hrmnk	V1	V2	V3	I1	I2	I3
%THD	2,8	2,8	3,0	19,4	31,2	29,7
%H15	0,5	0,3	0,4	0,6	12,5	9,5
%H17	0,6	0,4	0,6	1,2	10,9	12,7
%H19	0,2	0,3	0,5	0,7	6,5	6,8
%H21	0,2	0,2	0,4	0,5	4,2	6,3
%H23	0,2	0,2	0,2	0,3	2,8	7,0
%H25	0,0	0,0	0,0	0,0	0,2	1,4
S.No:00189101		CT: 5/5	26.05.2021		11:22	
%HV-HI ↓	%HV-HI ↑	Energy	HV_Rms	MENU		


Voltage-Current Harmonics (%)						30.0 °C
Hrmnk	V1	V2	V3	I1	I2	I3
%THD	2,9	2,8	2,7	19,6	31,0	29,5
%H27	0,0	0,0	0,0	0,0	0,5	3,0
%H29	0,1	0,1	0,1	0,1	1,0	4,6
%H31	0,0	0,0	0,0	0,0	0,6	3,2
S.No:00189101		CT: 5/5	26.05.2021		11:22	
%HV-HI ↓	%HV-HI ↑	Energy	HV_Rms	MENU		

### 3.5. Cosine and Phase Diagram Main Screen

The next screen shows the smart phasor diagram. The smart phasor diagram allows the user to observe the phase angles between current and voltage.




The phasor diagram has a thick circle on the outside and a thin circle inside it. The short thick and colored sticks between these circles show the angles of the phase voltages. The colored sticks inside the inner circle show the angles of the phase currents. At the same time, the lengths of these current sticks change dynamically based on the size of the current. In this way, the user can understand the size of the current values of each phase from the lengths of the current sticks. To help with angle reading, there are black thick lines at 30° intervals and short thin lines at 10° intervals on the inner circle of the diagram. This allows the user to better observe the angles by looking at these lines.



While on this screen, you can switch to the **Power Factor - Cosφ - Tanφ** sub-screen by pressing the **PFCosTan** button.

### 3.5.1. Power Factor

On the right side of the screen, power factors are shown for each phase separately. The left side of the screen also shows the cosine and tangent values for each phase separately.



## 3.6. Energy Indices

### 3.6.1. Energy Consumption

The screen on the left shows the active, inductive and capacitive energy values consumed. OBIS codes of the consumed energies are also shown on this screen.

Energy Consumption		30.0 °C
Active 1.8.0	000.000.047 Wh	
Inductive 5.8.0	000.000.002 VARh	
capacitive 8.8.0	000.000.001 VARh	
S.No:00189101		CT: 5/5
Energy(Urt)		Rate(Urt)
Cosφ		HD_VI
26.05.2021		11:22
MENU		

While on this screen, you can switch to the [Energy Productions](#) sub-screen by pressing the [Energy \(Urt.\)](#) button.

### 3.6.2. Energy Production

The next screen shows the active, inductive and capacitive energy values generated. OBIS codes of the generated energies are also shown on this screen.

Energy Production		30.0 °C
Active 2.8.0	000.000.024 Wh	
Inductive 7.8.0	000.000.042 VARh	
capacitive 6.8.0	000.000.052 VARh	
S.No:00189101		CT: 5/5
Energy(All)		Energy(Consumption)
Cosφ		HD_VI
26.05.2021		11:22
MENU		

While on this screen, you can switch to the [All Energies](#) sub-screen by pressing the [Energy \(All\)](#) button.

### 3.6.3. All Energies

The next screen shows the active, inductive and capacitive energy values produced and consumed. OBIS codes of the generated and consumed energies are also shown on this screen.

All Energies					30.0 °C
1.8.0	Imp	Active	000.000.024 Wh		
5.8.0	Imp	Inductive	000.000.043 VArh		
8.8.0	Imp	Capacitive	000.000.054 VArh		
2.8.0	Exp	Active	000.000.048 Wh		
7.8.0	Exp	Inductive	000.000.002 VArh		
6.8.0	Exp	Capacitive	000.000.001 VArh		
S.No:00189101		CT: 5/5	26.05.2021		11:22
Rate (Consumption)	Energy(Urt)	Cosφ	HD_VI	MENU	

### 3.6.4. Energy Rates (Consumption)

The next screen shows the inductive and capacitive energy consumed separately for each phase.

Energy Rates (Consumption)					30.0 °C
%Inductive Rate_L1	3,7	%Capacitive Rate_L1	1,3		
%Inductive Rate_L2	0,0	%Capacitive Rate_L2	1253		
%Inductive Rate_L3	0,0	%Capacitive Rate_L3	83,6		
%Inductive ΣRate	3,6	%Capacitive ΣRate	2,0		
S.No:00189101		CT: 5/5	26.05.2021		11:22
Rate(Urt)	Energy(All)	Cosφ	HD_VI	MENU	

While on this screen, you can switch to the [Energy Ratios \(Production\)](#) sub-screen by pressing the [Ratio \(Production\)](#) button.

### 3.6.5. Energy Ratios (Production)


The next screen shows the ratios of inductive and capacitive energy produced separately for each phase.

Energy Ratios (Production)					30.0 °C
%Inductive Rate_L1	0,0	%Capacitive Rate_L1	255		
%Inductive Rate_L2	207	%Capacitive Rate_L2	8731		
%Inductive Rate_L3	175	%Capacitive Rate_L3	0,0		
%Inductive ΣRate	174	%Capacitive ΣRate	218		
S.No:00189101		CT: 5/5	26.05.2021		11:22
Energy (Consumption)	Rate (Consumption)	Cosφ	HD_VI	MENU	

## 4. ANALYZER MAIN MENU



### 4.1. Fast Menu

This menu can be used to quickly change the current transformer ratio and modbus address of the device.



#### 4.1.1. Current Transformer Ratio

In this menu, the current transformer ratio is set.




Within the current transformer window, the current transformer ratio will flash. The current transformer ratio can be set to the required value by using the up and down arrow keys. By pressing the **Confirm** button, the requested value is confirmed.



### 4.1.2. Modbus Address

In the communication settings menu, settings related to Modbus communication of the device are made. Modbus address can take values between 1 - 247. After selecting the required value, it is confirmed by pressing the **Confirm** button.



NOTE : The device's factory default Modbus address is 1.

## 4.2 Analyzer

### 4.2.1. Harmonics

**MENU** > **Analyzer** > **Harmonics**

#### Profile

**Between 1-13 Single:** Demonstration of single harmonics of current and voltage between 1 and 13

**Pair between 1-13:** Demonstration of pair harmonics of current and voltage between 1 and 13

**All between 1-13:** Demonstration of all harmonics of current and voltage between 1 and 13

**Between 1-31 Single:** Demonstration of single harmonics of current and voltage between 1 and 31

**Pair between 1-31:** Demonstration of pair harmonics of current and voltage between 1 and 31

**All between 1-31:** Demonstration of all harmonics of current and voltage between 1 and 31

**All Harmonics:** Demonstration of all harmonics of current and voltage

**Detail:** In case you want to create a special harmonic profile, this option should be selected. By selecting this option, the harmonic values to be measured will be the harmonics set via the detail menu.

#### Detail

If detail is selected via the Profile menu, the harmonics to be measured will be monitored according to the limit and analysis values selected via this menu.

**Limit:** The limit of the harmonics to be measured can be set via this menu.

**Analysis:** It is possible to select whether the harmonics selected via the Limit menu are single, double or all.

#### 4.2.2. Delete Energies

Menu > Analyzer > Energies

If you want to reset the energy values, select the "Yes" option with the direction buttons and confirm this option with the Confirm button. Thus, the energies are deleted.

#### 4.2.3. Delete Peak Values

Menu > Analyzer > Delete Values

This is the menu where minimum and maximum values of electrical quantities are reset.

If you want to reset the peak values, select the "Yes" option with the direction buttons and confirm this option with the Confirm button. In this way, Peak values are deleted.

#### 4.2.4. Demands

Menu > Analyzer > Demands

This is the menu where the periods of Demand values are set and the values are reset.

**Demand Period :** Demand period can be set between 1-60 minutes. The setting process is done with the direction buttons. The required value is selected with the Confirm button.

⚡ NOT: The factory default demand period of the device is 15 minutes.

**Delete Demands:** If you want to reset the demand values, select "Yes" option with the direction buttons and confirm this option with the Confirm button. Thus, demand values are deleted.

## 4.3. Digital Output

Menu > Digital Output

This is the menu where the settings of the optocoupled digital output on the analyzer are made. The settings related to the digital output are given in the sub-headings.

### 4.3.1. Select Size

Menu > Digital Output > Select Size

In this section, the user selects the parameter to be associated with the digital output.


**Reactive Power:** Output controls are based on reactive power. When the reactive power parameter is selected, the upper limit point represents the magnitude (-999 / 999,9) required for the analyzer output to be "ON". If the reactive power value is higher than the upper limit value, the analyzer output turns "ON" and the relay symbol on the information sticker turns off and turns green. If the value is less than the lower limit value, the relay switches to "Off".

NOTE : Values are compared in absolute value.

NOTE : The values entered are in KiloWatt and KiloVAr.

**Active Power:** Output controls are based on active power. When the active power parameter is selected, the upper limit point refers to the magnitude (-999 / 999.9) required for the analyzer output to be "ON". If the active power value is higher than the upper limit value, the analyzer turns the output "ON" and the relay symbol on the information bar turns off and turns green. If the measured active power value falls below the lower limit value while the output is ON, the output turns "OFF".


NOTE : Values are compared in absolute value.



**Rate:** Output controls are based on energy ratios. When the ratio parameter is selected, the upper limit point represents the magnitude (0 - 999.9%) required for the analyzer output to be "ON". If the energy ratios are higher than the upper limit value, the analyzer output will turn "ON" and the relay symbol on the information stick will turn off and turn green.


NOTE : The values displayed on the screen are in percent.

NOTE : "Upper limit value" indicates the "+", inductive value of the reactive energy ratio, while "lower limit value" indicates the "-", capacitive value.




**Tangent:** Output controls are made through the tangent parameter. When the tangent parameter is selected, the lower limit point represents the magnitude (between 0 - 99.99 tan) required for the analyzer output to be "ON". If the tangent value is higher than the upper limit value, the analyzer output turns "ON" and the relay symbol on the information bar turns off and turns green.


NOTE : Upper limit value indicates the "+", inductive value of the Tangent. Lower limit value "-" indicates the capacitive value of the tangent.



**Power Factor:** Output control is made through the power factor (PF) parameter. When the power factor parameter is selected, the lower limit point represents the magnitude (between 0.75 and 1) required for the analyzer output to be "OFF". If the power factor value is less than the upper limit value, the analyzer output will be "ON" and the relay symbol in the information bar will be off and light green. If it is higher than the upper limit value, the output is "OFF".




**Cosine:** Output controls are made through the cosine(cos) parameter. When the cosine parameter is selected, the lower limit point represents the magnitude (between 0.75 and 1) required for the analyzer output to be "OFF". If the cosine value is less than the upper limit value, the analyzer output will be "ON" and the relay symbol on the information stick will turn off and light green. If it is higher than the upper limit value, the output is "OFF".



**Current:** Output controls are made through current parameter. If the current parameter is selected, the upper limit value point expresses the magnitude (0-9999) required for the output to be "ON". If the current value is higher than the upper limit value, the analyzer turns the output "ON" and the relay symbol on the information bar turns off and turns green. If the current value is less than the lower limit value, the analyzer output turns "OFF" and the relay symbol on the information stick turns on and goes out.

NOTE : The values entered are in Amps and Volts.

**Voltage:** Output control is made through the voltage parameter. If the voltage parameter is selected, the upper limit value point expresses the magnitude (between 0-9999) required for the output to be "ON". If the voltage value is higher than the upper limit value, the analyzer turns the output "ON" and the relay symbol on the information bar turns off and the relay symbol turns green. If the voltage value is less than the lower limit value, the analyzer output turns "OFF" and the relay symbol on the information stick turns on and goes out.



The upper limit and lower limit point shown in the figure are the points current and voltage points. If selected from the "select phase" menu mode (e.g. L1 phase) is higher than the upper limit value, the analyzer makes the output "ON". If the measured value is less than the lower limit value the analyzer makes the output "OFF".

**Remote Control:** Output controls are made remotely, through Modbus (communication).

**None of them:** For output control, no parameter is selected.

### 4.3.2. Select Phase

Menu > Digital Output > Select Phase

From the "Select Phase" menu, the selected output shows what the control parameter should operate on.

- L1 Phase Only
- L2 Phase Only
- Only L3 Phase
- Any Phase
- Three Phase Averaging

### 4.3.3. Invert Output

Menu > Digital Output > Invert Output

If you enter the "Invert Output" menu and select "Yes", the digital outputs are set to the opposite of the current state.

### 4.3.4. Upper Limit Value

Menu > Digital Output > Upper Limit Value

This is the tab where the alarm upper limit value is entered.

### 4.3.5. Lower Limit Value

Menu > Digital Output > Lower Limit Value

This is the tab where the alarm lower limit value is entered.

### 4.3.6. Start-up Time

Menu > Digital Output > Start-up Time

In case the relevant electrical values exceed the upper limit value, the time to wait for output is determined.

### 4.3.7. Deactivation Time

Menu > Digital Output > Deactivation Time

In case the relevant electrical values fall below the lower limit value, the time to wait for the output to turn OFF is determined.

## 4.4. Events

Menu > Events

This is the menu where settings such as listing and deleting alarm conditions on the device and activating the alarm icon are made.

### 4.4.1. List

Menu > Events > List

This section lists the date and time of the alarm conditions that occur on the device and how many times they occur.

#### 4.4.2. Alarm Icon

Menu > Events > Alarm Led

In case of an alarm occurring during the operation of the device, this option must be set to "Activated" when the alarm symbol is to be colored red.

#### 4.4.3. Delete

Menu > Events > Delete

The alarm conditions that occur are deleted.

### 4.5. User Manual



Menu > User Manual

This menu displays a QR code that directs you to the website where the user manual is available.

### 4.6. Settings

Menu -> Settings

The Settings menu is the menu where the settings of the device are made.

#### 4.6.1. Measurement & Transformers

Menu > Settings > Measurement & Transformers

In this menu, the current transformer ratio is set to the required value between 5/5 - 10000/5. In the current transformer window, the present current transformer ratio will flash. Here, the current transformer ratio can be set to the required value by using the up and down arrow keys. The requested value is confirmed by pressing the **confirm** button.

**Voltage Transformers:** It is the menu where line voltage and measurement voltage settings are made.

**Line Voltage:** In this menu, the line voltage is set to the required value in the range 173 V - 46000 V. In the line voltage window, the current line voltage values will flash. The line voltage can be set to the required value by using the up and down arrow keys. The required value is confirmed by pressing the **confirm** button.



**Measuring Voltage:** In this menu, the measuring voltage is set to the required value in the range 22 V - 725 V. In the measurement voltage window, the current measurement voltage values will flash. The measurement voltage can be set to the required value by using the up and down arrow keys. The required value is confirmed by pressing the **Confirm** button.

#### 4.6.2. Modbus Settings

**Menu** > **Settings** > **Modbus Settings**

In the Modbus settings menu, the settings related to the Modbus communication of the device are made.

**Modbus Address:** The device is assigned a different Modbus address from other connected devices. The values are changed between 0-247 with the direction keys and the required address can be given to the device with the **Confirm** key.

**Modbus Speed:** The Modbus communication speed (Baud Rate) of the device is determined. The speeds can be changed with the direction keys and the required communication speed can be selected with the **Confirm** button.

If "4800" is selected, the communication speed is 4800 bps.

If "9600" is selected, the communication speed is 9600 bps.

If "19200" is selected, the communication speed is 19200 bps.

If "38400" is selected, the communication speed is 38400 bps.

If "57600" is selected, the communication speed is 57600 bps.

If "115200" is selected, the communication speed is 115200 bps.

**Reading Protection:** If you enter the menu and select "Yes", the user is asked for a password to read the device remotely via Modbus communication.

#### 4.6.3. Screen Settings

**Menu** > **Settings** > **Screen Settings**

**Password Protection:** In case you want to restrict access to the menus of the device, this option must be activated. This way a password is required to access certain menus.

**Access Level:** Enables encrypted activation of access levels.

**Waiting Time:** The required time for the device's screen saver to start working is selected with this option. This parameter can be set between 1-30 minutes.

**Brightness Level:** When you want to change the brightness setting of the TFT screen on the device, you can change the brightness value in % from this option.

#### 4.6.4. Date & Time

**Menu** > **Settings** > **Date & Time**

If you want to set the date and time of the device, you can change the related date and time parameters via this menu.

### 4.6.5. Expert Settings

Menu > Settings > Expert Settings

**Factory Settings:** Enables the device to return to factory settings.

**Device Reset:** Enables the device to be reset.

**Energy Period:** This is the menu where the energy period of the device is set.

**Quality Control:** If the device has failed the quality control test during production, it is used to re-perform the quality control test.

### 4.6.6. Device Information

Menu > Settings > Device Information

**Serial Number:** If it is required to observe the serial number of the device, the serial number can be viewed via this menu.

**Software Version:** This is the screen where the version of the device's software is monitored.

**Hardware Version:** This is the screen where the hardware version of the device is observed.

**Language:** When you want to change the language of the device, you can select Turkish/English language on this screen.